

Quick Fix

WATERSLIDE DECALS
from FOURDEES



APPLICATION INSTRUCTIONS

If applying the decal as a single sheet, we recommend that you first coat the finished model in a suitable high gloss varnish and/or Micro-Set decal adhesive.

Cut around each lining segment as closely as possible. If the panel is large, we recommend scoring out the clear central panel.

Submerge the transfer into cold water for 10 seconds, or until the paper begins to roll up.

Rub the decal carefully between the fingers in order to remove the transfer foil from the backing card. Now you can slide the transfer on to the desired surface (we recommend using tweezers to hold the decal in this process). For larger designs, try and slide off the transfer directly from the carrying card on to the model.

If you need to adjust the decal, apply water with a paintbrush to help release it from the surface. We recommend using a cocktail stick to help position the decal.

Once you are happy with the position, use kitchen roll or a cotton wool bud to soak up the water on and around the decal. To avoid air bubbles, streak with the cotton bud from the centre to the edge of the foil. Leave it to dry for 3 hours.

To make the transfers more durable, cover them with clear varnish. If fitting over surface detail (such as rivets) we recommend a coat of Micro-Sol decal softener.

If air bubbles appear later, prick them with a pin and re-seal.

Web: www.fourdees.co.uk

Address: 57 Wentworth Road, Blacker Hill, Barnsley, S74 0RP

Email: info@fourdees.co.uk